








AOC 24E3QAF Disassembly SOP

Step	Figure	Description
<p>Remove stand / base from monitor</p>		<ul style="list-style-type: none"> ● Place the monitor face down to the soft surface. ● Remove the screws ● Press release button to take out stand.
<p>Remove back cover</p>		<ul style="list-style-type: none"> ● Release screws. ● Use tool to open all the latches. ● Disconnect cable to remove back cover.




Remove main frame


- Tear out all the tapes
- Disconnect cable
- Release screw
- Lift up main frame to disconnect cable




Remove boards
from main frame



Take out mylar
Release screws.




Take out middle frame



Release screws.

Remove speakers



Disconnect cables